

MBC-SERIES

SEMI-AUTOMATIC BLADE COATER



RECOMMENDED SPARE PARTS LIST

<i>PART NUMBER</i>	<i>DESCRIPTION</i>
21-0341	Air Gauge
21-0339	Air Regulator
01-0023A	Arm Inserts (Coating Arm)
28-0053	Idler Roll Bearings
01-0198	Coating Arm Assembly
01-0191	Idler Rolls (Input & Output)
01-0166	Rotohead Assembly
17-0072	Speed Sensor
17-0026	Speed Switch
01-0171	Suction Tube Assembly
01-0108	Supply Nozzle
19-0084	Supply & Return Pump
19-0093	Pump Repair Kits

MBC-SERIES

SEMI-AUTOMATIC BLADE COATER



CONSUMABLE PARTS LIST

PART NUMBER	DESCRIPTION
31-0002	Backup Blade
31-0001	Coating Blade (Hard Fiber)
15-0005	Coating Blade (Soft Fiber)
18-0007	3/8 Quick Dis. Rubber Air Hose
15-0016	Mylar w/ Velcro
12-0153	1/4" x 2 1/2" Cotterless Pin
28-0011	Left-Hand Ruler
28-0012	Right-Hand Ruler
01-0172-A	Adjusting Plate
01-0176-A	Mounting Tube
12-0156	U-Bolt
12-00072	1/2" Hex Nut
12-0006	Velcro Loop